



1401 S. Broadway Suite 103A | Joshua, TX 76058

## INSTALLATION INSTRUCTIONS

### RR AIR PUMPER MOUNT

PPX-1423S

Read Instructions entirely, and view illustrations before beginning.

ITEM	DESCRIPTION	QTY
	Left Side Bracket	1
	Right Side Bracket	1

ITEM	HARDWARE	QTY
	M6 Button Head Bolt	4



### Have questions or comments?



817-366-6110



817-366-6110



INFO@ABFFABRICATION.COM

*Thank You for Sharing*



FACEBOOK.com/ABFfabrication



### LIABILITY STATEMENT

ABF Fabrication accessories are engineered to best fit customer ATV/UTV's in stock condition. cutting, grinding, or modifying any original, or aftermarket, accessories will void any warranty offered by ABF fabrication and is not suggested. ABF Fabrication accessories could have fitment issues with other aftermarket accessories. If Customer has aftermarket accessories on vehicle, contact ABF Fabrication to ensure that all accessories will be compatible.

Customer should be aware that installing suspension accessories, wheels and tires, axles or other components may change the behavior of the vehicle and may require more frequent maintenance and part wear. Operating any off-road vehicle while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this accessories ability to protect customer from severe injury or death. ABF Fabrication urges operators and passengers to always wear a helmet and appropriate riding gear.

By purchasing and installing ABF Fabrication accessories, customer agrees that should any damages occur, ABF Fabrication will not be held responsible for repair fees, replacement parts, and shipping costs. ABF Fabrication, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any accessories purchased from ABF Fabrication. The total liability of ABF Fabrication to customer for all damages, losses, and causes of action, if any, is not to exceed the total purchase price paid for the accessories that gave rise to the claim.

ABF Fabrication will warranty only accessories purchased from ABF Fabrication. Any damages or issues arising with OEM parts or other manufacturers accessories will not be covered by ABF Fabrication. ABF Fabrication accessories are not warranted if accessory was installed incorrectly, misused, or changed in any way.

### Tools Needed

1. 4mm Allen Wrench
2. T40 Torx Bit
3. Ratchet / Impact

### Removal

1. Begin by removing the 2 center T40 bolts on the rear deck behind the seats. **NOTE** (You will be reusing these for install so keep them close by)

### Installation

**NOTE:** We recommend you **DO NOT TIGHTEN** all hardware until the end unless otherwise noted. Just snug the hardware so that the parts can moved/adjusted slightly.

1. Install the brackets onto the rugged air pumper using the 4 m6 button head bolts. Ensure that the flange faces to the outside of the pumper. Tighten just one side and leave the other side bracket slightly loose to make it easier to install in the vehicle.
2. Align the pumper brackets with the 2 center holes on the rear deck behind the seats. Re-install the two t40 bolts and tighten.
3. At this point you can go ahead and tight the two m6 bolts that you left loose in step 1.
4. Your Rugged Air Pumper is now mounted to your RZR Pro. Follow Rugged's instructions for wiring.

**FIG 1**

